

Seinätukien asennus

Seinätuet asennetaan molemmin puolin seinää. Sovita seinätuet paikoilleen ja poraa uran yläkolmanneksen kohdalta reiät hirteen pultteja varten 10 mm poralla. Kiinnitä liukulevyt seinätukien urien päälle. Asenna pultit, aluslevyt ja mutterit kuvien mukaan. Poraa seinään alas 10 mm reikä ja kiinnitä seinätuet alhaalta pultilla. Seinätukia voi tarvittaessa lyhentää alapäästä. Poraa silloin uusi reikä alapäähän. Älä kiristä ylempiä pultteja liian tiukalle, jotta hirsiseinä pääsee elämään pystysuunnassa.

Alla olevista detaljikuvista on hirsiseinä seinätukien välistä piilotettu.

Installing wall supports

The wall supports are installed on both sides of the wall. Place the wall supports to the wall and drill 10 mm holes to the wall log in the top third of the grooves. Fasten the metal plates on the grooves with screws. Install bolts, spacers and nuts as shown. Drill a 10 mm hole to the wall at bottom and fasten the wall supports to the wall with a bolt. The wall supports can be shortened by cutting at the bottom end, if needed. Drill a new hole in that case. Do not overtighten the bolts in the grooves for letting the wall to move vertically.

The wall between the wall supports is hidden from the detail drawings below.

